






Accessories for hand-held scanner BCS 3600-NI series

for ATEX/IECEX Zone 2/22 and CSA Class I, II, III Div. 2



Ordering information

Accessories for use in potentially explosive atmospheres

Illustration	Description	Order no.
	Battery for hand-held scanner BCS 3678 ^{ex} -NI Lithium-ion battery 3.6 V/3150 mAh May only be changed outside the potentially explosive atmosphere!	B7-A2Z0-0036
	High quality leather holster for hand-held scanner series BCS - for attachment to a belt or wall - Colour: black	17-A1Z0-0024
	Connection cable Connection between universal supply module and scanner 1.9 m (plain) 4.5 m (plain)	B7-A2Z0-0037 B7-A2Z0-0038
	2.7 m (spiral)	B7-A2Z0-0039
	HMI limiting cable Connection between HMI and scanner 1.9 m (plain) USB 1.9 m (plain) RS232 4.5 m (plain) RS232; can be individually shortened	B7-A2Z0-0041 B7-A2Z0-0040 B7-A2Z0-0050


Ordering information

Accessories for use outside potentially explosive atmospheres

Illustration	Description	Order no.
	<p>4-slot battery charger</p> <p>for hand-held scanner BCS 3678^{ex}-NI and BCS 3678^{ex}</p> <ul style="list-style-type: none"> - Input voltage: DC 12 V (50 W) - Charging display via LED and sound <p>Additionally required: (not included in delivery)</p> <ul style="list-style-type: none"> - Power pack - DC connecting cable - AC power cable 	<p>G7-A0Z0-0013</p>
	<p>Base station</p> <p>for hand-held scanner BCS 3678^{ex}-NI and BCS 3678^{ex}</p> <ul style="list-style-type: none"> - Input voltage with RS232: DC 12 V - Input voltage with USB: 5 V - Multipoint Interface: compatible with up to 7 scanners - LED charge function and charging indicator - IP 65 <p>Additionally required: (not included in delivery)</p> <ul style="list-style-type: none"> - Power pack - AC power cable - Connecting cable 	<p>G7-A0Z0-0014</p>

Ordering information

Accessories for use outside potentially explosive atmospheres

Illustration	Description	Order no.
	<p>Programming cable For programming BCS 3600^{ex}-NI 1.9 m (plain)</p>	B7-A2Z0-0046
	<p>Power supply for base station - Input voltage: AC 100 V to 240 V - Output voltage: DC 12 V/4, 16 A/50 W</p>	G7-A0Z0-0011
	<p>Power supply for 4-slot battery charger - Input voltage: AC 100 V to 240 V - Output voltage: DC 12 V/4, 16 A/50 W</p>	G7-A0Z0-0019
	<p>DC connecting cable Connection between power pack and 4-slot battery charger</p>	G7-A0Z0-0028
	<p>AC power cable - US + Canada - LATAM - EU + APAC - TAIWAN</p>	G7-A0Z0-0024 G7-A0Z0-0025 G7-A0Z0-0026 G7-A0Z0-0027
	<p>Connecting cable Connection between PC and base station - RS232: 2 m (plain) - RS232: 4.6 m (plain) - RS232: 2.8 m (spiral) - USB: 2 m (plain) - USB with power supply: 12 V, 2 m (plain)</p>	G7-A0Z0-0014 G7-A0Z0-0015 G7-A0Z0-0016 G7-A0Z0-0017 G7-A0Z0-0018
	<p>Special tool for lock nut for hand-held scanner BCS 3678^{ex} - For opening and locking the special lock - 5 pieces</p>	G7-A0Z0-0031